



ESPRESSO MACHINE (BACKFLUSH)

1. Place one (1) tablet into blind portafilter. Use two (2) for heavily used machines.
2. Run 10 seconds. Wait 5 seconds.
3. Repeat 'Run' cycle 3 more times.
4. Rinse portafilter and wipe slot.
5. Machine is clean and ready.

PORTAFILTER, BASKET, STEAMING TIP, FROTHING CUP, MILK SPOON & OTHER ACCESSORIES

1. Make a solution dissolving three (3) tablets in 20 oz. of hot water. Add extra tablet for heavy stains.
2. Soak at least 2-3 hours or overnight.
3. Wipe or brush off any excess stains.
4. Rinse*.

AUTOMATIC ESPRESSO MACHINE

Follow manufacturer cleaning instructions using Everest Natural Descaler.

General Guidelines:

1. Make a solution dissolving three (3) tablets in 20 oz. of water in the water container.
2. Press button to extract hot water/coffee.
3. Spray the steam nozzle.
4. Repeat process three (3) more times with clean water (until foam subsides).
5. Machine is clean and ready.

❑ TIP: Tablets dissolve faster in hot water and stirred

COMMERCIAL COFFEE GRINDER (to clean and remove excess oils)

1. Remove excess coffee in the grinder.
2. Take (12) twelve tablets and **BREAK THEM IN HALF**. Place the broken tablets into the hopper.
3. Grind tablets on **COURSE GRIND** setting.
4. Place about 2 oz. of coffee beans in hopper and grind through to remove excess cleaner.
5. Discard coffee.

WATER BOTTLES, THERMOS, BLENDERS

1. Fill bottle, thermos or blender with water.
2. Use one (1) tablet per 12 oz. of water. Use two (2) for heavy stains.
3. Soak at least 2-3 hours or overnight.
4. Wipe or brush off any excess stains.
5. Rinse*.

DISHWASHER SANITIZER

1. Remove all dishes from dishwasher.
2. Place six (6) tablets in place of detergent.
3. Run normal cycle.

OTHER USES

1. Baby bottles & Utensils
2. Portable – great for camping or travelling
3. Fruits & Vegetables
4. Drinking Straws & Tubes
5. Cups & Mugs
6. Lids with hard to clean areas

❖ **To clean and sanitize straws, tubes, lids and other tight areas – just soak for at least a few hours or overnight and rinse**

***Conserve water, Everest Natural Descaler is non-toxic and rinses off easily with no residue.**

- ❖ For Espresso Machines, our solution rinses off completely after 4 run cycles - no residue
- ❖ Espresso is clean and tastes great from the 1st pull - save water and coffee
- ❖ After soaking, stains may still be visible, but should wipe off easily with towel or sponge
- ❖ Tablet may take up to 15 min to dissolve - To dissolve faster, use hot water and stir
- ❖ **For best results and tough stains, use an extra tablet in hot water and soak overnight**

